



A WILDFIRE PRO SHOP COMPANY

FIREPROSHOP
889 TAHOE BLVD., UNIT A
INCLINE VILLAGE, NV 89451
909-519-5470
FIREPROSHOP.COM



SNAP-PLATE MOLD DEFENDER™ · FIELD APPLICATION GUIDE

Treat the plate line before the walls stand.

Once the walls are up and the drywall is on, the underside of the bottom plate is the one surface on the job nobody can reach again.

THE METHOD – FOUR STEPS, NO CHANGE TO LAYOUT

- 01 Snap your lines as usual**
Nothing about layout changes. The framer works off the same lines.
- 02 Roll three inches wide of the line**
The extra width is what interrupts horizontal moisture movement into the plate.
- 03 Coat the bottom of each plate**
Done on the deck, before the walls are stood.
- 04 Stand the walls and keep framing**
Single application, roller or sprayer. The walls go vertical on the same schedule.



5 - GALLON

TEST STANDARD	APPLICATION	WHERE	SIZES
ASTM G21	Roller or sprayer, single coat	Snapped lines & plate bottoms	1 · 5 · 55 gallon

**Fifteen minutes, and we will walk
your framing sequence with you.**

NO COST
TO GET NUMBERS

STEVE CONBOY · 909-519-5470
SALES@FIREPROSHOP.COM
FIREPROSHOP.COM